

To replace an old rear shock, our technicians recommend the following procedure:

Remove the old rear shock and check its length.

Measure the following dimensions of the unloaded rear shock:

1. length of the rear shock in mm (centre – centre)
2. width of upper mount in mm
3. width of lower mount in mm
4. inner diameter of bushing in mm

Please measure to the nearest tenth of a millimetre!



1. Length of the rear shock



2. Upper mount



3. Lower mount



4. Bushing inner Ø