



Rear offset measurement

Info: a seat post's offset to the rear is measured from the centre of the seat post to the centre of the saddle clamp, with the clamp head at 90° to the post. To reduce the clamping forces on aluminium and carbon seat posts, we recommend to use the Dynamic assembly paste, item no. 253772.