



Height of top part

When buying a suspension seat post, please consider that it may have to protrude more from the frame than the one that you used before. The “height of the top part” specified is measured from the top edge of the saddle tube to the bottom edge of the saddle frame. This dimension is labelled **A** in our diagram. You must maintain this spacing, as otherwise the frame or the seat post may be damaged when the springs compress.